This camera list updates on Dec 17th, 2019

FeiyuTech

AK2000S Camera Compatibility List（Cable Control）

BRAND	CAMERA LIST	CONTROL CABLE	FUNCTION	SETTING NOTES ON CAMERA/LENS	CAMERA VERSION	HUB FIRMWARE
Sony	a6300	Type-C to Multi Shutter cable	1. Take photos 2. Start/Stop recording video 3. Manually Focus/zoom 4. Switch between photos/video mode	1. USB 2.0 to micro (A01) is available to charge the camera and Type-C to Multi Shutter cable can not charge the camera . 2. We recommend Type-C to Multi Cable to control Sony camera. 3. Please turn on the gimbal, and then plug in the cable.	2.00	AK2000S_HUB_V102
	a6400				1.00	
	a6500				2.00	
	a6100				1.00	
	a6600				1.00	
	a7R IV				1.00	
	a7R III				3.01	
	a7 III(A7M3)				3.00	
	a7SII				2.00	
	a7RIII				4.00	
	a7II				4.00	
	a9				2.00	
	a7R				6.00	
	RX10 IV(RX10M4)				1.30	
	RX100 VII(RX100M7)				1.00	
	RX10 IV				—	

BRAND	CAMERA LIST	CONTROL CABLE	FUNCTION	SETTING NOTES ON CAMERA/LENS	CAMERA VERSION	HUB FIRMWARE
Canon	M50	USB 2.0 to micro (A01)	1. Take photos 2. Start/Stop recording video	—	1.0.0	AK2000S_HUB_V102
	EOS R	USB 2.0 to TypeC(C01)	1. Take photos 2. Start/Stop recording video 3. Follow focus electrically	When using Follow focus electronically, the lens needs to be in AF mode	1.0.0	
	EOS RP			—	1.3.0	
	M6 mark II			—	1.0.0	
	G7X mark III		1. Take photos 2. Start/Stop recording video	Please turn off the WIFI connection for Cable control.	1.0.1	
	EOS 90D	USB 2.0 to micro (A01)	1. Take photos 2. Start/Stop recording video 3. Follow focus electrically 4. Switch between photos/video mode	When using Follow focus electronically, the lens needs to be in AF mode	1.0.0	
Panasonic	GH5s	USB 2.0 to TypeC(C01)	1. Take photos 2. Start/Stop recording video 3. Follow focus electronically	1. USB mode choose PC(Tether) 2. WIFI and USB cable control cannot be used simultaneously 3. When using Follow focus electronically, the lens needs to be in AF mode	1.2	
	GH4	Panasonic Shutter cable TYPE C to DC2.5	1. Take photos 2. Start/Stop recording video	1. To control recording, you need to turn the camera to video mode .	2.7	
	G9				2.0	

BRAND	CAMERA LIST	CONTROL CABLE	FUNCTION	SETTING NOTES ON CAMERA/LENS	CAMERA VERSION	HUB FIRMWARE
Nikon	Z7	USB 2.0 to TypeC(C01)	1. Take photos 2. Start/Stop recording video 3. Follow focus electrically	1. After turning on the camera, it takes a few seconds for the camera to connect successfully 2. Make sure the camera has wire function is on when using the global control function (UI) 3. To control recording, you need to turn the camera to video mode . 4. When using follow focus electronically, the lens needs to be in AF mode and very slow	1.00	AK2000S_HUB_V102
	Z6				2.00	
Fujifilm	X-T30	Type-C to TRS2.5 (T02)	1. Take photos 2. Start/Stop recording video 3. Manually Focus	1. Please set up "MIC/REMOTEO-RELEASE "to REMOTE， Steps: Press Menu，Video Setting2 MIC/REMOTEO-RELEASE2 REMOTE 2. To control recording, you need to turn the camera to video mode .	1.00	AK2000S_HUB_V102
	X-T20				2.01	
	X-A7		1. Take photos 2. Manually Focus	Please set up "MIC/REMOTEO-RELEASE "to REMOTE， Steps: Press Menu，Shooting Setting3 MOVIE SET-UP3 MIC/REMOTEO-RELEASE2 REMOTE	1.00	
	X-A5				2.00	
	X-T100				2.00	
	XH-1		1. Take photos 2. Start/Stop recording video 3. Half-press to focus	—	2.01	
	XT-3				3.01	

AK2000S Camera Compatibility List（WIFI Control）

BRAND	CAMERA LIST	TAKE PHOTO	START/STOP RECORDING VIDEO	SWITCH PHOTO/VIDEO	ZOOM IN&OUT	FOLLOW FOCUS	SPECIFICATION ADJUSTMENT	REMARK
Sony	RX100 V(RX100M4)	✓	✓	×	✓	×	EV	
	RX100 V(RX100M5)	✓	✓	×	✓	×	EV	
	RX100 VI(RX100M6)	✓	✓	×	✓	×	WB,ISO,EV	
	RX100M5A	✓	✓	×	✓	×	WB,ISO,EV	Enter the interface of smartphone control
	a5100	✓	✓	✓	✓	×	EV	
	a6000	×	×	×	✓	×	EV	
	a6100	✓	✓	×	✓	×	WB,ISO,EV	
	a6300~16-50	✓	✓	×	✓	×	WB,ISO,EV	
	a6500~28-70	✓	✓	×	×	×	EV	
	a6400~24-70	✓	✓	×	✓	×	WB,ISO,EV	Enter the interface of smartphone control
	a9	✓	✓	×	×	×	WB,ISO	
	a7 III (A7M3)	✓	✓	×	✓	×	WB,ISO	Enter the interface of smartphone control
	a7R III	✓	✓	×	×	×	WB,ISO,EV	
	a7 II (A7M2)	✓	✓	×	×	×	EV	
	a7S II	✓	✓	×	✓	×	EV	
	a7R II	✓	✓	×	×	×	EV	
	a7S	✓	✓	×	×	×	EV	
	a7R	✓	✓	×	✓	×	EV	
	a7	✓	×	×	×	×	EV	

BRAND	CAMERA LIST	TAKE PHOTO	START/STOP RECORDING VIDEO	SWITCH PHOTO/VIDEO	ZOOM IN&OUT	FOLLOW FOCUS	SPECIFICATION ADJUSTMENT	REMARK
Canon	M50	✓	✓	✓	×	×	—	
	EOS R	✓	✓	✓	×	×	ISO,EV	
	EOS 200D	✓	✓	✓	×	✓	WB,ISO,EV	
	M6 mark II	✓	✓	✓	×	×	ISO,EV	
	EOS RP	✓	✓	✓	×	×	ISO	Steps to connect WIFI：WIFI SETTING—Camera Control APP—CONNECT。 For the first WIFI connection, please activate APP function，please ask for help from official support of Feiyu Tech or Canon.
	G7X mark III	✓	✓	✓	×	✓	ISO	

BRAND	CAMERA LIST	TAKE PHOTO	START/STOP RECORDING VIDEO	SWITCH PHOTO/VIDEO	ZOOM IN&OUT	FOLLOW FOCUS	SPECIFICATION ADJUSTMENT	REMARK
Panasonic	GH4	✓	✓	✓	×	×	WB,ISO,EV	After 20 seconds of connecting WIFI, the camera prompts: the monitor screen is closed, and the Panasonic official APP has the same problem. The camera's internal settings cannot be improved.
	GH5	✓	✓	✓	×	✓	WB,ISO,EV	
	GH5S	✓	✓	✓	×	✓	WB,ISO,EV	
	DC-G85GK-K	✓	✓	✓	×	✓	WB,ISO,EV	
	DC-GF9GK	✓	✓	✓	×	✓	WB,ISO,EV	
	DC-GF9KGK	✓	✓	✓	×	✓	WB,ISO,EV	
	DC-GF10KGK	✓	✓	✓	×	✓	WB,ISO,EV	
	DC-ZS70GK	✓	✓	✓	✓	✓	WB,ISO,EV	
	DC-ZS220GK	✓	✓	✓	✓	✓	WB,ISO,EV	
	DMC-ZS110	✓	✓	✓	✓	✓	WB,ISO,EV	
	DMC-GX85	✓	✓	✓	×	✓	WB,ISO,EV	
	DMC-LX100	✓	✓	✓	✓	✓	WB,ISO,EV	
	DMC-LX10	✓	✓	✓	✓	✓	WB,ISO,EV	

AK2000S Lens Compatibility List

BRAND	CAMERA LIST (WIDTH/HEIGHT/DEPTH/WEIGHT)	LENS MODEL	LENS SIZE & WEIGHT (DIAMETER* LENGTH)	EQUIP CAMERA LENS	EQUIP CAMERA&FOLLOW FOCUS	REMARK
Sony	a9: 128.9×95.6×63mm 580g a7RIII:128.9×96.4×77.5mm 657g a7RII: 128.9×95.6×62.5mm 572g a7MII: 128.9×95.6×73.7mm 569g a7RI: 128.9×95.6×52.7mm 572g a7S2: 128.9×95.7×60.3mm 584g a7R2: 128.9×95.7×60.3mm 582g a7M2: 128.9×95.7×59.7mm 556g a7S:128.9×94.4×48.2mm 449g a7R:128.9×94.4×48.2mm 407g a7: 126.7×94.4×48.2mm 416g	E 10-18mm F4 OSS	070mm*63.5mm 225g	Support	Support
		FE 12-24mm F4 G	087mm*113mm 565g	Support	Support
		FE 16-35mm F2.8 GM	088mm*122mm 680g	Support	Support
		FE16-35mm F4 ZA OSS	078mm*99mm 518g	Not Support	Support
		FE 24-70mm F4 ZA OSS	073mm*98.5mm 426g	Support	Support
		FE 24-70 F2.8 GM	087.6mm*128mm 886g	Not Support	Not Support	The lens is too long and too heavy to be balanced
		Zeiss E 16-70 F4 OSS	066.6mm*75mm 308g	Support	Support
		E PZ 18-105mm F4 G OSS	078mm*120mm 427g	Support	Support
		E PZ 18-200mm F3.5-6.3 OSS LE	083.2mm*99mm 649g	Not Support	Not Support	The lens diameter is too large and the installation may interfere
		FE 8-24 f/2.8 G OSS	093.4mm*113.3 mm 981g	Support	Support
		FE 28-70mm F3.5-5.6 OSS	072.5mm*93mm 295g	Support	Support
		FE 28mm F2	064mm*60mm 208g	Support	Support
		Zeiss FE 35mm F2.8 ZA	061.5mm*36.5mm 129g	Support	Support
		Sigma 30mm F1.4 DC DN	064.8mm*73.3mm 265g	Support	Support
		Sigma 35mm F1.4 DG HSM A+	077mm*94mm 665g	Support	Support
		FE 50mm F1.8	064mm*72mm 281g	Support	Support
		FE 50mm F2.8 MACRO	071mm*72mm 236g	Support	Support
		FE 85mm F1.4 GM	089.5mm*107.5mm 820g	Support	Support
		E 10-18mm F4 OSS	070mm*63.5mm 225g	Support	Support
		FE 12-24mm F4 G	087mm*113mm 565g	Support	Support
		FE 16-35mm F2.8 GM	088mm*122mm 680g	Support	Support
		FE16-35mm F4 ZA OSS	078mm*99mm 518g	Support	Support
		FE 24-70mm F4 ZA OSS	073mm*98.5mm 426g	Support	Support
		FE 24-70 F2.8 GM	087.6mm*128mm 886g	Not Support	Not Support	The lens is too long and too heavy to balancing
		Zeiss E 16-70 F4 OSS	066.6mm*75mm 308g	Support	Support
		E PZ 18-105mm F4 G OSS	078mm*120mm 427g	Support	Support
		E PZ 18-200mm F3.5-6.3 OSS LE	083.2mm*99mm 649g	Not Support	Not Support	The lens diameter is too large and the installation may interfere
		FE 8-24 f/2.8 G OSS	093.4mm*113.3 mm 981g	Support	Support
		E 3.5-5.6/PZ 16-50 OSS	064.7mm*29.9mm 116g	Not Support	Not Support	The lens is too short to fit the follow focus
		FE 28mm F2	064mm*60mm 208g	Support	Support
		Zeiss FE 35mm F2.8 ZA	061.5mm*36.5mm 129g	Support	Support
		Sigma 30mm F1.4 DC DN	064.8mm*73.3mm 265g	Support	Support
		Sigma 35mm F1.4 DG HSM A+	077mm*94mm 665g	Support	Support
		FE 50mm F1.8	064mm*72mm 281g	Support	Support
		FE 50mm F2.8 MACRO	071mm*72mm 236g	Support	Support
		FE 28-70mm F3.5-5.6 OSS	072.5mm*93mm 295g	Support	Support
		FE 85mm F1.4 GM	089.5mm*107.5mm 820g	Support	Support
	a6400 :120×67×60mm 355g a6300 :120×66.9×60.6mm 361g a6500 :120×66.9×53.3mm 415g	RX100 III (A7M3)	Pocket Camera	Support	Not Support	Pocket Camera can not be equipped with follow focus
		RX100 V 101.6×58.1×41.4mm 298g	Pocket Camera	Support	Not Support	Pocket Camera can not be equipped with follow focus
		RX100 VI 101.6×58.1×41mm 299g	Pocket Camera	Support	Not Support	Pocket Camera can not be equipped with follow focus
		RX10 III 101.6x61.1x42.2mm 301g	Pocket Camera	Support	Not Support	Pocket Camera can not be equipped with follow focus
		RX100 VII 101.6×58×42.8mm 337g	Pocket Camera	Support	Not Support	Pocket Camera can not be equipped with follow focus

BRAND	CAMERA LIST (WIDTH/HEIGHT/DEPTH/WEIGHT)	LENS MODEL	LENS SIZE & WEIGHT (DIAMETER* LENGTH)	EQUIP CAMERA LENS	EQUIP CAMERA&FOLLOW FOCUS	REMARK
Panasonic	GH5S 138.5×96.1×87.4mm 660g GH5 138.5×96.1×87.4mm 725g G9 138.5×97.3×93.6mm 650g GH4:93.4×83.9×112.9mm 560g	LEICA DG SUMMILUX 25mm F1.7	115.86g	Support	Not Support	Pocket Camera can not be equipped with follow focus
		LEICA DG SUMMILUX 25mm F1.4	077.7mm*75mm 510g	Support	Support
		LEICA DG MACRO-Elmarit 45mm F2.8 OIS	063mm*92.5mm 225g	Support	Support
		LEICA DG Vario-Elmarit 8-18mm F2.8-4.5 ASPH	073.4mm*85mm 335g	Support	Support
		LEICA DG Vario-Elmarit 12-60 f/2.8-4 Power OIS	068mm*98mm 320g	Support	Support
		H-ZLX40 DIGITAL 50-150mm F2.8	050mm*87mm 430g	Support	Support
		LUMIX G 14-140mm F3.5-5.6 II ASPH	070mm*84mm 460g	Support	Support
		LUMIX G Vario 12-35mm F2.8 II ASPH POWER OIS	068mm*74mm 305g	Support	Support

BRAND	CAMERA LIST (WIDTH/HEIGHT/DEPTH/WEIGHT)	LENS MODEL	LENS SIZE & WEIGHT (DIAMETER* LENGTH)	EQUIP CAMERA LENS	EQUIP CAMERA&FOLLOW FOCUS	REMARK
Nikon	Z6 :134×100.5×67.5mm 675g Z7 :134×100.5×67.5mm 675g	NIKKOR Z 24mm f/1.8	77g	Support	Support	
		S 14-24mm f/2.8 S G ED VR	087mm*77mm 455g	Support	Support
		NIKKOR Z 50mm f/1.8 S	61g	Support	Support
		NIKKOR Z 24-70mm f/4 S	50g	Support	Support
		NIKKOR Z 14-30mm f/4 S	085mm*99mm 485g	Support	Support

BRAND	CAMERA LIST (WIDTH/HEIGHT/DEPTH/WEIGHT)	LENS MODEL	LENS SIZE & WEIGHT (DIAMETER* LENGTH)	EQUIP CAMERA LENS	EQUIP CAMERA&FOLLOW FOCUS	REMARK
Canon	EOS R :135.0×98.4×84.6mm 660g EOS RP :132.5×85.9×70mm 485g	RF 24mm F1.8 MACRO IS STM	074.4mm*52.8mm 305g	Support	Support	
		RF 5.1X 28mm F3.5-5.6 IS	070.5mm*120mm 595g	Support	Not Support	After adding the follow focus, the center of gravity is at the front and cannot be balanced
		RF 24-70mm EN IS USM	085.4mm*93mm 680g	Support	Not Support	After adding the follow focus, the center of gravity is at the front and cannot be balanced
		RF 35mm F1.8 MACRO IS STM	069mm*109mm 335g	Support	Support
		RF 50mm F1.2 L USM	088.5mm*96.8mm 475g	Support	Support
		RF 85mm F1.2L USM	088.8mm*128mm 950g	Support	Support
		RF 28-70mm F2L USM	0103.6mm*128.8mm 1430g	Not Support	Not Support	The lens is too long to be balanced
		RF 24-105mm F4L IS USM	085.5mm*107.3mm 670g	Support	Not Support	After adding the follow focus, the center of gravity is at the front and cannot be balanced
	M50 :116.3×88.1×58.7mm 387g	EF-M 15-45mm F3.5-6.3 IS	170g	Support	Not Support	The lens is short and cannot be equipped with follow focus

BRAND	CAMERA LIST (WIDTH/HEIGHT/DEPTH/WEIGHT)	LENS MODEL	LENS SIZE & WEIGHT (DIAMETER* LENGTH)	EQUIP CAMERA LENS	EQUIP CAMERA&FOLLOW FOCUS	REMARK
Fuji	X-T2: 110×92×49mm 437g X-T3: 121×92.8×58.8mm 539g	XF 16mm f/1.4 R WR	073mm*72mm 375g	Support	Support
		XF 23mm f/1.4 R	072mm*53mm 300g	Support	Support
		XF 35mm f/1.4	065mm*54.5mm 187g	Support	Support
		XF 10-24mm f/4.0 R OIS	078mm*87mm 410g	Support	Support
		XF 16-55mm f/2.8 R LM WR	083.3mm x 106.0mm 655g	Support	Support
		XF 10-24mm f/2.8 R WR	086mm*93.4mm 335g	Support	Support
		XF 18-135mm f/3.5-5.6 R LM OIS WR	078mm*98mm 490g	Support	Support
	X-H1: 139.8×97.2×85.5mm 673g	XF 16mm f/1.4 R WR	073mm*73mm 375g	Support	Support
		XF 23mm f/1.4 R	072mm*53mm 300g	Support	Support
		XF 35mm f/1.4	065mm*54.5mm 187g	Support	Support
		XF 10-24mm f/4.0 R OIS	078mm*87mm 410g	Support	Support
		XF 16-55mm f/2.8 R LM WR	083.3mm x 106.0mm 655g	Support	Support
		XF 10-24mm f/2.8 R WR	086mm*93.4mm 335g	Support	Support
		XF 18-135mm f/3.5-5.6 R LM OIS WR	078mm*98mm 490g	Support	Support
	X-T20: 110.4×92.8×41.4mm 383g X-T30: 118.4×82.8×46.8mm 383g	XF 16mm f/1.4 R WR	073mm*73mm 375g	Support	Support
		XF 23mm f/1.4 R	072mm*53mm 300g	Support	Support
		XF 35mm f/1.4	065mm*54.5mm 187g	Support	Support
		XF 10-24mm f/4.0 R OIS	078mm*87mm 410g	Support	Support
		XC 16-50mm f/3.5-5.6 OIS	062.6mm*59.2mm 195g	Support	Support
		XF 16-55mm f/2.8 R LM WR	083.3mm x 106.0mm 655g	Support	Support
		XF 10-24mm f/2.8 R WR	086mm*93.4mm 335g	Support	Support
		XF 18-135mm f/3.5-5.6 R LM OIS WR	078mm*98mm 490g	Support	Support
		XC 15-45mm f/3.5-5.6 OIS PZ	062.6mm*59.2mm 125g	Support	Support

After adding the follow focus, the center of gravity is at the front and cannot be balanced.

Camera body is short， After adding the follow focus, the center of gravity is at the front and cannot be balanced